


- Sendersuchlauf
- Abnehmbarer Gürtelclip
- Stereo-Ohrhörer inklusive
- Handliche Geräteabmessungen
- Batteriebetrieb:2xUM-4/Micro (nicht enthalten)







**Operating Manual** 

- 1.Place two UM-4 hetteries into the hettery case, in the correct position.
- 2.Use a 3.5mm steree earphone and plug into the corphone socket.
- 3. Switch on the power/volume coetrol and adjust the volume level to your requirement.
- 4. Press reset button once and then press soon button once. This will oute soon to a channel. When pressing many times and on affect, you should press the reset button once end then the scen hutton egain, till you reach your fevourite station.

## **UKW MINI RADIO**

Bedienungsanleitung

- 1.Plazieran Sie zwei UM-4 Betteriae ie des Batteriafach. Achten Sie debei euf die richtige Positien.
- 2. Stecken Sie die 3.5mm Steree-Ohrhörer in die Dhrhörer-Anschlussbuchsen.
- 3. Bedienes Sie des power/volume-Schelter und regulieres Sie die Leutstärke.
- 4.Drückee Sie dee reset-Knepf. Drückee Sie dene den scen-Keepf eiemel, se wird ein Seuder eingestellt, Weun usch mehrmeligem Drückee kein Ergebeis erreicht wurde, drückee Sie den reset-Knopf noch eiemal und daeach noch eiemal des scen-Koopf selenge bis Sie Ihree Lieblingssender eiegestellt habee.





elta GmbH, D-63322 Roedermark

71-0000721-21